


SETPOINT (Cutout) ST1



PARAMETERS
C1 = Min compressor off time (stops short cycling)
C7 = Max pump down time
C8 = Comp. delay after opening of solenoid valve
C9 = Enable auto start (multiple pump down attempts)
A5 = 8 (LP switch on D.I. 2)
H1 = 5 (Enable solenoid valve output)